






Spare Parts



17




18




20


14




16



15




19



7



4



2

1

6

8


5

3

12

11

10



9

13

| SKETCH NO. | SPAREPART NO. | Sweet 750 tvättställskåp sidoskåp | Sweet 750 under cabinet side cabinet |
|------------|---------------|--|--|
| 1 | 9203610 | SWEET 250 HURTS VÄNSTER GAVEL VIT | SWEET 250 SIDE CABINET LEFT SIDE WHITE |
| 2 | 9203611 | SWEET 250 HURTS HÖGER GAVEL VIT | SWEET 250 SIDE CABINET RIGHT SIDE WHITE |
| 3 | 9203612 | SWEET 250 HURTS TOPP/BOTTEN VIT | SWEET 250 SIDE CABINET TOP/BOTTOM WHITE |
| 4 | 9203613 | SWEET 250 HURTS ÖVRE HÄNGREGEL VIT | SWEET 250 SIDE CABINET UPPER BACK STRIP WHITE |
| 5 | 9203614 | SWEET 250 HURTS NEDRE HÄNGREGEL VIT | SWEET 250 SIDE CABINET LOWER BACK STRIP WHITE |
| 6 | 9203615 | SWEET 250 HURTS MELLANREGEL VIT | SWEET 250 SIDE CABINET 45 DEGREED ANGLE BOARD WHITE |
| 7 | 9203616 | SWEET 250 HURTS VÄGGREGEL VIT | SWEET 250 SIDE CABINET MIDDLE STRIP WHITE |
| 8 | 9203617 | SWEET 250 HURTS HYLLA VIT | SWEET 250 SIDE CABINET SHELF WHITE |
| 9 | 9203618 | SWEET 250 HURTS/HALV-/HÖGSKÅP LÅDA VÄNSTER GAVEL | SWEET 250 SIDE-/HIGH-/HALF CABINET DRAWER LEFT SIDE WHITE |
| 10 | 9203619 | SWEET 250 HURTS/HALV-/HÖGSKÅP LÅDA HÖGER GAVEL | SWEET 250 SIDE-/HIGH-/HALF CABINET DRAWER RIGHT SIDE WHITE |
| 11 | 9203620 | SWEET 250 HURTS LÅDBOTTEN VIT | SWEET 250 SIDE CABINET DRAWER BOTTOM WHITE |
| 12 | 9203621 | SWEET 250 HURTS LÅDA BAKRE GAVEL VIT | SWEET 250 SIDE CABINET DRAWER BACK SIDE WHITE |
| 13 | 9203622 | SWEET 250 HURTS LÅDFRONT VIT | SWEET 250 SIDE CABINET DRAWER FRONT WHITE |
| 14 | 9203624 | SWEET 750 TVÄTTSTÄLLSKÅP SKRUVPÅSE | SWEET 750 BASIN CABINET SCREW BAG |
| 15 | 9203625 | SWEET 250 HURTS/HALV-/HÖGSKÅP VÄNSTER LÅDSKENA | SWEET 250 SIDE-/HIGH-/HALF CABINET LEFT SLIDE |
| 16 | 9203626 | SWEET 250 HURTS/HALV-/HÖGSKÅP HÖGER LÅDSKENA | SWEET 250 SIDE-/HIGH-/HALF CABINET RIGHT SLIDE |
| 17 | 9203627 | SWEET HANDTAG | SWEET HANDLE |
| 18 | 9203628 | SWEET GÅNGJÄRN | SWEET HINGES |
| 19 | 9202969 | SWEET LUCKDÄMPARE | SWEET DAMPER |
| 20 | 9129301 | SWEET TVÄTTSTÄLL 750 VÄNSTER | SWEET WASH BASIN 750 LEFT |
| 20 | 9129302 | SWEET TVÄTTSTÄLL 750 HÖGER | SWEET WASH BASIN 750 RIGHT |

| | | | | |
|---|--|---|---|---|
|  | <p>Hafa Svarvaregatan 5, Box 525 SE-301 80 Halmstad SWEDEN</p> | <p>Garanti/Warranty. Service, resevdelar/spare-parts Sweden: Tel: +46 (0)35 15 44 75 Norway: Tel: +47 69 31 02 30 Finland: Puh: 0207 43 50 00</p> | <p>www.hafa.se www.hafa.dk www.hafabad.no www.hafa.se www.hafabathroom.ru www.hafa.eu</p> | <p>E-mail: service@hafa.se service@hafabad.no</p> |
|---|--|---|---|---|