


Spare Parts





Sharp

Art: 1381060

SCETCH NO	SPARE PART NO	SHARP TVÄTTSTÄLLSBLANDARE KROM	SHARP WASH BASIN MIXER CHROME
1	9209622	SHARP ENGREPPSHANDTAG	SHARP HANDLE
2	9209614	SHARP DEKORRING KROM	SHARP DECOR CAP UNDER HANDLE CROME
3	9209615	SHARP FIXERINGSMUTTER FÖR INSATS	SHARP LOCK RING FOR CARTRIDGE
4	9209549	SHARP INSATS 35 MM	SHARP CARTRIDGE 35 MM
5	9209604	SHARP PERLATOR	SHARP AERATOR
6	9209607	SHARP VERTYG TILL PERLATOR	SHARP KEY TO AERATOR
7	9209600	SHARP MONTERINGSSATS	SHARP ASSEMBLING KIT
8	9209601	SHARP ANSLUTNINGSSLANGAR 45 CM	SHARP FLEX INOX 45 CM
9	9209611	SHARP BOTTENPACKNING	SHARP BOTTOM GASKET



Hafa
Svarvaregatan 5, Box 525
SE-301 80 Halmstad
SWEDEN

Garanti/Warranty.
Service, resevdelar/spare-parts
Sweden: Tel: +46 (0)35 15 44 75
Norway: Tel: +47 69 31 02 30
Finland: Puh: 0207 43 50 00

www.hafa.se
www.hafa.dk
www.hafabad.no
www.hafa.se
www.hafabathroom.ru
www.hafa.eu

E-mail:
service@hafa.se
service@hafabad.no